


Ultra-thin LED remote control with touch slider

Model: R11

Functions




R11
1-zone

CE RoHS LVD RED

Features

- Apply to a single or double color
- Ultra-sensitive touch slider to adjust brightness
- The remote control can be connected to multiple receivers
- Powered by a CR2032 battery
- Has a LED indicator light
- Comes with a magnetic mount that can be mounted on a wall



Options for mounting the remote control with the handle:

1. Glue the remote control holder to any surface using double-sided mounting tape;
2. Attach the holder to the wall with two screws;
3. (Without using the handle) attach the remote control to a metal surface, thanks to the magnet in the remote control.

Pairing the LED remote control with the On/Off button

Connect:

Disconnect the power, then reconnect it, immediately press 3 times the On/Off button on the remote control quickly.

3 flashes of the LED on the remote control indicates successful pairing of the remote control with the receiver.

Disconnect:

Disconnect the power supply, then reconnect the power supply, Immediately press 5 times the On/Off button on the remote control quickly.

5 flashes of the LED on the remote control means successful disconnection with the receiver.


Safety information

1. Before pairing/installation/assembly, please read the instructions.
2. When installing the battery, pay attention to the anode and cathode of the batteries. When the remote control does not respond, or its range has decreased, replace the battery.
3. If the receiver does not respond, re-pair the the remote control.
4. Avoid dropping the remote control, as it may be damaged.
5. Use the remote control only indoors. Keep it in a dry and safe place.

Ultra-thin 4-zone LED remote control

Model: RU4

Functions



RU4
4-zone

CE RoHS LVD RED

Options for mounting the remote control with the handle:

1. Glue the remote control holder to any surface using double-sided mounting tape;
2. Attach the holder to the wall with two screws

Pairing the LED remote control with the On/Off button

Connect:

Disconnect the power, then reconnect it, immediately press 3 times quickly the On/Off button on the remote control for all zones (in case of one zone), or Zone on/Off (in case of multiple zones)..

3 flashes of the LED on the remote control indicates successful pairing of the remote control with the receiver.


Disconnect:

Disconnect the power supply, then reconnect it, immediately 5 times quickly press the button on the remote control to turn on/off all zones (for one zone), or Enable/Disable a zone (for multiple zones).

5 flashes of the LED on the remote control means successful disconnection with the receiver.

Features

- Allows control of four separate zones independently
- Apply to a single or double color
- The remote control can be connected to multiple receivers
- Powered by a CR2032 battery
- Has a LED indicator light
- Comes with a mount that can be mounted on a wall



Safety information

1. Before pairing/installation/assembly, please read the instructions.
2. When installing the battery, pay attention to the anode and cathode of the batteries. When the remote control does not respond, or its range has decreased, replace the battery.
3. If the receiver does not respond, re-pair the remote control.
4. Avoid dropping the remote control, as it may be damaged.
5. Use the remote control only indoors. Keep it in a dry and safe place.